



1. Turn off the general switch
2. Mark & drill holes, apply plastic anchors
3. Pull th wires through the hole
4. Connect wires
5. Apply the bulb into place
6. Fix the luminaire into place, by rotate
7. Turn on the general switch

