



1. Turn off the general switch
2. Drill holes & apply plastic anchors
3. Connect the wires
4. Fix it in place by tying up screws
5. Turn on the general switch

