


# NOVA LUCE


9191541

1




Turn off the general switch

2




Drill holes & apply plastic anchors  
With screws

3




Connect the wires

4




Apply the side screws

5




Apply the elements

6



Apply the bulb

7



Turn on the general switch

