


1

Indicator instructions:

1. The flashing green light indicates charging.
2. The steady green light indicates fully charged.

Note: Open the waterproof gasket before charge .
Don't forget to close it after full charge.






2

Touchdimmer:

- Touch1=100% of light-4 hours runtime
- Touch2=40% of light-10 hours runtime
- Touch3=10% of light-50 hours runtime
- Touch4=ON/OFF

Touch dimmer



Note:

Charge time: 3H(1A Charger adapter)

Charging Cable and Plug adapter included, Max Current 2A