


NOVA LUCE


9580602 , 9580603

1




Turn off the general switch

2




Mark where to drill holes

3




Make holes & apply anchors

4




Tie up the screws
to make it stable

5




Connect the wires

6



Put it in place
& Apply side screws

7



Turn on the general switch

8

