


## WIRING SCHEMATIC DIAGRAM FOR RECEIVER



## POWER PARAMETER LIST

Voltage	Fan(max.)	Lamp(max.)
220-240V	65W	115W
120V	60W	40W

## FUNCTION INSTRUCTION OF EMITTER

Adopt RF wireless digit emission technique, binunique controlled , coincident code rate is less than one millionth.(Emitter and receiver must be sent back to factory for maintenance if damaged). Receiver can be controlled by any angles of the emitter in prescriptive space, unrestricted by direction. With the memory function, the controller can save the status( light and direction ) while the supply power OFF and resume to the original after reload the power supply.

## KINDLY REMINDERS:

1. Learning code matching mode is used between emitter and receiver. Turn "ON" the supply power within 30 seconds and press the emitter's " " button for 5 seconds, it can load normally after hearing a long sound "bee", which means learning successfully and it can work normally. (PS: Learning mode is not accepted after turn "ON" the supply power for 30 seconds)
2. When the emitter cannot control the receiver, please check is there any existence of similar remote controlled products nearby, then check whether they work, because remote controlled product with the same frequency will disturb each other.
3. The maximum load of lighting see the above"POWER PARAMETER LIST"  
PS: please connect the ground wire correctly, otherwise it may cause the light micro-light or flash
4. When installing the fan, the fan ceiling cover don't press the antenna(or other wire), it's easy to breakdown the wire and short-circuited.

